

# Ohio Department of Transportation

## Prebid Questions

Project No. 090100

Sale Date - 2/4/2009

Question Submitted: 2/9/2009

Question Number: 1

Regarding the wingwalls on the box culvert. Are they to be precast or cast in place? If they can be precast how should we break apart the footer and connect the vertical wingwall to the footer. The plans make it look like it would be cast in place.

**The wingwalls and footers are to be cast-in-place.**

All prospective bidders, subcontractors, suppliers, materialmen and all others who have an interest in these prebid questions and answers are advised that these items are being provided for informational purposes only and are not part of the bidding documents. If a question warrants a clarification, the Department will issue an addenda addressing the request for clarification to all plan holders. If the Department believes that the bidding documents adequately address the request, the contractor will be advised accordingly.