



NOTES:

- 1.) SAFETY EDGES ARE REQUIRED AT THE OUTSIDE EDGES OF THE PAVED ROADWAY (EDGE OF TRAVEL LANE OR EDGE OF PAVED SHOULDER).
- 2.) CONSTRUCT THE SAFETY EDGE 4" THICK. CONSTRUCT A NEAR-VERTICAL FACE BELOW THE SAFETY EDGE.
- 3.) BLADE AND SHAPE EXISTING SHOULDER MATERIAL TO FORM A UNIFORM SURFACE UNDER THE SAFETY EDGE PRIOR TO PLACEMENT OF THE CONCRETE.

* 40° MAX

